



# Comfor™ Shoulder Abduction Pillow

## Application Instructions




**Step 1** - Separate components for ease of application.

- A. Shoulder Abduction Pillow
- B. Circumference Strap
- C. Padded Shoulder Strap
- D. Humeral Cuff
- E. Wrist/Hand Cuff




**Step 2** - Place shoulder abduction pillow under the arm, elevating the arm to desired degree of abduction, 45° or 70°.



**Step 3** - Secure in place by attaching the circumference strap to the pillow and wrapping around the patient's torso.



**Step 4** - Attach both cuffs to the abduction pillow. The wrist/hand cuff should be placed toward the outer edge of the pillow with the buckle closure towards the patient's body. Place arm in cuffs. Secure humeral and wrist/hand cuffs with hook closure. Adjust if necessary.



**Step 5** - Place padded shoulder strap over unaffected shoulder and secure hook closure to back of abduction pillow, as shown above. Secure to front by inserting strap through buckle closure on wrist/hand cuff. Adjust length of strap.



**Step 6** - Readjust circumference strap around abduction pillow if necessary.